

# *Harvia Fenix*



EN

Control Unit

Natural well-being. **HARVIA**<sup>®</sup>  
Sauna 

## CONTENTS


|   |          |   |           |
|---|----------|---|-----------|
| <b>FENIX WIRELESS CONTROL UNIT</b> .....                        | <b>3</b> | 2.9.2. Curve Diagram .....  | 14        |
| QUICK GUIDE .....   | 4        | 2.9.3. Adjust Current Time and Day ...  | 14        |
| FIRST SWITCH-ON .....   | 4        | 2.9.4. Device Pair-Up .....   | 14        |
| CHOOSING THE PANEL LANGUAGE .....                               | 4        | 2.9.5. Panel Power Settings .....   | 15        |
| SETTING THE TIME AND DAY .....                                  | 4        | 2.9.6. Additional Options and Settings  | 15        |
| CONNECTIONS BETWEEN DEVICES .....                               | 4        | 2.9.7. Detailed Version Info.....   | 15        |
| DEVICE PAIR-UP .....  | 4        | 2.9.8. Sensor Reading Adjustment .....  | 15        |
| HEATING UP THE SAUNA .....                                      | 5        | 2.9.9. Service Menu.....  | 15        |
| SETTING THE PRE-SETTING TIME -<br>delayed heating.....          | 5        | a) Auxiliary Relay Function .....   | 15        |
| <b>1. HARVIA FENIX CONTROL UNIT</b> .....                       | <b>6</b> | b) Installed/Enabled Features .....   | 15        |
| 1.1. General .....  | 6        | c) Heater Watts Setup .....   | 15        |
| 1.2. Technical Data.....  | 6        | d) Steamer Watts Setup.....   | 15        |
| 1.3. Configurations .....                                       | 7        | e) Max On Time Setup.....   | 15        |
| <b>2. INSTRUCTIONS FOR USE</b> .....                            | <b>7</b> | f) Load Factory Settings.....   | 15        |
| 2.1. General .....  | 7        | 2.10. Options.....  | 15        |
| 2.1.1. Batteries .....  | 7        | 2.10.1. Calibrating the Touch Screen .  | 16        |
| 2.2. Function Menus in the Main Menu<br>and Function Icons..... | 7        | <b>3. INSTRUCTIONS FOR INSTALLATION</b> .....                                   | <b>18</b> |
| 2.3. Sauna Time Setup.....                                      | 8        | 3.1. Installing the Wireless Control Unit .....                                 | 18        |
| 2.4. Heater and Steamer Setup .....                             | 8        | 3.2. Installing the Power Unit .....  | 20        |
| 2.4.1. Heater Setup .....                                       | 8        | 3.2.1. Electrical Connections of Power<br>Unit SACF150 for Heater .....         | 20        |
| 2.4.2. Steamer Setup .....                                      | 8        | 3.2.2. Electrical Connections of Power<br>Unit SACF165S for Steamer/Heater ...  | 20        |
| 2.5. Colour Light and Light Setup .....                         | 10       | 3.2.3. Electrical Installations of Power<br>Unit SACF100 for Colour Light ..... | 20        |
| 2.5.1. Colour Light Setup.....                                  | 10       | 3.2.4. Installing the Radio Antenna ....  | 26        |
| 2.5.2. Light Setup.....   | 11       | 3.2.5. Installing the Temperature<br>and Humidity Sensors.....                  | 26        |
| 2.6. Fan Setup .....  | 11       | 3.2.6. Resetting the Overheat<br>Protector.....                                 | 27        |
| 2.7. Week Timer .....   | 12       |   |           |
| 2.8. User Settings.....   | 13       |   |           |
| 2.9. Miscellaneous .....  | 14       |   |           |
| 2.9.1. Statistics.....  | 14       |   |           |

Congratulations on choosing a Fenix control unit by Harvia!

With Fenix you can control all functions of your sauna via the user-prompting touch screen of a wireless control unit. You can control the temperature, humidity, colour lights, and all other aspects – from your couch. A novelty that makes it possible for you to enjoy your sauna in a variety of new ways!


## FENIX WIRELESS CONTROL UNIT

(The displayed view varies according to the features acquired and enabled.)



Touch screen of the wireless control unit

### Fitting and changing the batteries to the wireless control unit, behind the display



## Start Menu

(The displayed view varies according to the features acquired and enabled.)

### Function Icons

|  |                     |  |                          |
|--|---------------------|--|--------------------------|
|  | Light ON/OFF        |  | Sauna ON/OFF             |
|  | Fan ON/OFF          |  | Set the Pre-Setting Time |
|  | Colour Light ON/OFF |  | Main Menu                |
|  | Heater ON/OFF       |  |                          |
|  | Steamer ON/OFF      |  | Function ON              |
|  |                     |  | Function OFF             |

Under the **Sauna ON/OFF** icon you'll find information on the conditions in your sauna, offering short cuts to change the settings affecting the current sauna bath.


The icons in the top row provide short cuts to active functions, for example **Colour Light Settings**.

Short cut to **Temperature Settings**.

Short cut to **Graph View**.

Short cut to **Weekday and Time Settings**.

**Sauna OFF**



The icon in the upper right corner indicates the power source (batteries or charger). It does not indicate what the charge level is or when charging is required.

Short cut to **Steamer Settings**.

Short cut to **Operating Time Settings**.

To the **Main Menu** by pressing the function icon  
In Sauna ON mode, you can also switch to Main Menu by pressing the power switch lightly. The link to the Main Menu appears on the screen.

## Main Menu - Function Menus

(The displayed view varies according to the features acquired and enabled.)




Main Menu, page 1



Page change



Main Menu, page 2



Back to the Start Menu

## Controls in Menu



Confirm



Exit/Cancel



Arrow  
icons



Track  
bar

## QUICK GUIDE

### FIRST SWITCH-ON

First time when you switch on the wireless control unit, it will automatically prompt you to calibrate the touch screen. The unit will guide you through the calibration process. After this you need to choose the desired panel language and set the day and time. Make the required settings and confirm. If the unit does not follow the above steps automatically, they can be carried out manually:

### CALIBRATING THE TOUCH SCREEN (see section 2.10).

### CHOOSING THE PANEL LANGUAGE

1. **Start Menu** (the first menu to appear after switching on).
2. Press the **Main Menu** icon. Use the page change to scroll through the Main Menu to **User Settings** and select.
3. Use the page change to scroll to **Panel Language** and select.
4. Choose a language and **Confirm**.
5. Press the **Exit** icon to return to the Start Menu.

### SETTING THE TIME AND DAY

1. Press the **Main Menu** icon. Use the page change to scroll through the Main Menu to **Miscellaneous** and select.
2. Use the page change to scroll to **Adjust current time** and select.
3. **Set day** and confirm.
4. **Set time** and confirm.

### CHOOSING THE DEVICES TO BE ENABLED (see Service menu 2.9.9. b).

### CONNECTIONS BETWEEN DEVICES

An icon in the upper left corner of the screen indicates whether the connections are active or whether there are lost connections or new devices to be connected. When connections are lost it can also be a case that the wireless control unit is outside the operating range (ca. 10 m) of the radio link.

Missing connections are established through device pair-up. See the following quick tips or chapter 2.9.4. 'Device Pair-Up' (further below).



**Connection active** – this icon is displayed while the devices are communicating with each other.



**No connection** – this icon is constantly displayed while the connections are disconnected.


**DEVICE PAIR-UP**

The following pair-up procedure is necessary to make the devices recognize each other and communicate:


1. Switch on the wireless control unit. The **Start Menu** is displayed.
2. Press the Main Menu icon. Use the page change to scroll through the Main Menu to **Miscellaneous** and select.
3. Use the page change to scroll to **Device Pair-Up** and select. This is the procedure to be used to establish a connection between devices/device pairs.
4. Under the selected menu item you will find the pair-up procedure menu. When you are establishing connections between device pairs for the first time, select **Help**. Read through the instructions and follow them.
5. Press the **Confirm** icon to switch back to the **Pair-Up Procedure** menu:



Pair-Up Procedure



Pair-Up Help, page 1




Pair-Up Help, page 2


**A) Click 'New code'**, and the display will show 'Panel code changed. Renewing pairs is necessary.'

**C) Click 'Heater'**, and the display will show 'Linking to Heater, switch power on now.'

**D) Turn power unit on within 10 seconds**, and the display will show 'Successful pair-up with heater.' If the pairing up was not successful, the display will show "Pair-up with heater FAILED". In this case, return to Step B and repeat the procedure according to the instructions.



Pair-Up icon for heater power unit



Pair-Up icon for colour light power unit

6. To further add colour light, for example, press **'Colour light'**.

**NOTE!** If you press the 'New Code' icon again, all connections are lost and must be re-established!

**HEATING UP THE SAUNA**

1. **Start Menu** (the first menu to appear after switching on).
2. Use the function icons to switch functions on or off.  
**Light ON/OFF, Sauna ON/OFF, Heater ON/OFF, Steamer ON/OFF** (model SACF165S)  
 While an icon is activated, the corresponding function is on. The display shows up-to-date information on your sauna, including the temperature, humidity and remaining operating time.
3. All displayed data can be changed. Go to settings by pressing the relevant reading or the icon up on the screen. Make the desired changes and confirm or cancel to return to the previous screen. Any confirmed changes only affect the current bath.
4. When active icons are deactivated, the corresponding functions are switched off, and the display will show a recap of the most recent sauna bath, including the total time and energy consumption. Touch the screen to return to the Start Menu.

**SETTING THE PRE-SETTING TIME - delayed heating**

1. Press the **Set the Pre-Setting Time** icon.
2. Set the desired **Delay** after which the heater should start heating up the sauna. Use the arrow icons, which enable an accurate setting, or the track bar.
3. Confirm by pressing the **Sauna ON** icon or cancel if you wish to make other settings. This takes you back to the Start Menu.
4. While the function is activated, the display shows up-to-date information on your sauna, including the temperature, humidity and remaining time to heating. Activate from the current display **Heater ON**  and/or **Steamer ON**,  depending for which function you wish to set the pre-setting time.
5. To activate other functions, press the displayed function icons, for example **Light ON**.

## 1. HARVIA FENIX CONTROL UNIT

### 1.1. General

Harvia Fenix is a multidimensional control unit that makes it possible for you to enjoy your sauna in a wider variety of ways. The Fenix control unit allows you to totally control your sauna and the bathing conditions, such as the temperature, humidity and ventilation.

The control unit consists of a wireless control unit (touch screen), a power unit/power units and a sensor/sensors. The touch-screen control unit communicates with the power unit wirelessly or, alternatively, via a cable. See Figure 1.

The control unit can be used to control sauna heaters and Combi combined heaters/steamers within an output range of 2,3–15 kW. The Fenix wireless control unit operates to a distance of about 10 metres from the power unit, depending on structural obstacles.

### 1.2. Technical Data

#### Wireless control unit:

- Touch screen for controlling the sauna by selecting the desired functions and settings. Equipped with rechargeable batteries. The recharge stand must be placed in a dry place outside the sauna room. See Figure 2.
- Operating voltage 3,6 V.
- Temperature adjustment range 40–110 °C.

- Humidity adjustment range 20–95 % RH.
- Operating time adjustment range:
  - family saunas 0,5–6 h, no week timer
  - public saunas in apartment buildings 0,5–12 h, required pause time min. 6 h.*For longer operating times consult the importer/manufacturer.*
- Pre-setting time adjustment range 0–18 h.
- Programmable week timer.
- Lighting control, max. power 100 W, 230 V 1N~
- Fan control, max. power 100 W, 230 V 1N~
- Colour light control, max. power 2 x 50 W colour light unit 12 V DC.

#### Power units:

- Supply voltage 400 V 3N~
- Max. load 15 kW/400 V 3N~
- The power units are placed in a dry place outside the sauna room. They must not be embedded within the wall structure.

#### Sensors:

- The temperature sensor is equipped with a resettable overheat protector and a temperature-sensing NTC thermistor. The sensor is installed in the sauna room according to the instructions given in chapter 3.2.5. 'Installing the Temperature and Humidity Sensors'.
- The humidity sensor measures relative humidity. The sensor is installed in the sauna room according to the instructions given in chapter 3.2.5. 'Installing the Temperature and Humidity Sensors'.




Figure 1. Interconnected devices of a Fenix control unit.

### 1.3. Configurations

The Harvia Fenix control unit consists of different devices which together allow comprehensive control over all aspects of sauna bathing. Available device packages are:

**SACF10** wireless control unit for controlling power units, incl.

- Touch screen (wireless control unit)
- Recharge stand
- Wall-mounting plate for recharge stand
- Charger
- 3 AA rechargeable batteries
- Instructions for installation and use.

**SACF150** power unit for controlling heater (max. 15 kW), incl.

- Power unit SACF150 for heater control
- Radio antenna and cable for communication with wireless control unit
- Temperature sensor
- Humidity sensor (available as an accessory)

**SACF165S** power unit for controlling combined heater/steamer (max. 16,5 kW), incl.

- Power unit SACF165S for heater/steamer control
- Radio antenna and cable for communication with wireless control unit
- Temperature sensor
- Humidity sensor

**SACF100** power unit for controlling colour light, incl.

- Power unit SACF100 for controlling colour light units max. 2 x 50 W
- Cable for connection to power unit SACF150 or SACF165S

## 2. INSTRUCTIONS FOR USE

Before you switch the heater on check always that there aren't any things over the heater or in the near distance of the heater.

### 2.1. General

The wireless control unit is equipped with a user-prompting touch screen and is operated by three AA rechargeable batteries. The unit comes with a recharge stand. The recharge stand can be mounted into the wall or to the table but it must be placed outside the sauna room. **Never take the wireless control unit to a heated sauna!**

The wireless control unit is activated by pressing the black power switch above the screen. Activation brings the **Start Menu** with the function icons to the screen. Pressing a function icon switches the corresponding function on or off. Activated functions are indicated by a dark spot in the corner of relevant function icons and by 'active function' images above the screen.

The touch screen can be operated using a finger or, for example, the blunt end of a pencil. **Avoid pressing the screen unnecessarily hard!**

Clean the touch screen from time to time with a cloth or mild alcohol wipe.

### 2.1.1. Batteries

The instructions for fitting/changing the batteries can be found on page 59. The Fenix wireless control unit comes with NiMh AA HR6 rechargeable batteries, voltage 1,2 V. The rechargeable batteries can be replaced with non-rechargeable AA batteries. **Note! Never place the wireless control unit in the recharge stand when fitted with non-rechargeable batteries. Do not use rechargeable and non-rechargeable batteries simultaneously together.**

New, unused batteries must be charged uninterruptedly for 24 hours before use. A complete recharge takes 12 hours. It is recommended to keep the wireless control unit in the supplied recharge stand when the unit is not in use – this way the batteries have charge when the unit is needed again.

**Never use a damaged charger or battery.** Remove the damaged battery from the unit. Dispose of the batteries according to the local regulations (concerning recycling etc.). Do not place batteries in household waste. Remove the batteries before disposing of the unit. Remove the unit from the charger before fitting/changing batteries.

### 2.2. Function Menus in the Main Menu and Function Icons

You can control all functions of your sauna using the function menus or the function icons.

#### Function Icons

**Light, Fan and Colour Light** are activated by pressing the relevant function icon on the screen.



#### Sauna ON/OFF

Press the **Sauna ON/OFF** icon to enable communication between the power unit and the wireless control unit. The wireless control unit now displays information on the conditions in your sauna, such as temperature and humidity. Should the connection between the power unit and the wireless control unit be lost during the bath, the power unit will nevertheless be able to perform the programmed functions since all the settings remain stored in its memory.

Settings (operating time, temperature, humidity etc.) made in the **Sauna ON** mode only affect the current bath.

Settings made in the **Sauna OFF** mode are default settings which are stored in the memory of the wireless control unit.



The **Set the Pre-Setting Time** icon takes you directly to the screen where you can set the pre-setting time.



Pressing the **Main Menu** icon brings the function menus to the screen.

Through the Main Menu you can change all the settings related to your sauna. The function menus are explained in detail further below.

**The pictures shown in this manual are meant as guidelines only since the screens may vary according to which features have been acquired and enabled for use.**




Function icons can be added and removed from the screen. See 2.9.9. 'b) Installed / Enabled Features'.

### 2.3. Sauna Time Setup

Through the **Sauna Time Setup** menu you can make timer settings for your sauna.

- **The operating time** is the time the heater is on.
- **The pre-setting time** is the delay period after which the heater starts heating up the sauna. Do not forget to activate **Heater ON** and/or **Steamer ON** icon on the screen, depending for which function you wish to set the pre-setting time.

From the Main Menu choose



### 2.4. Heater and Steamer Setup

#### 2.4.1. Heater Setup

Under the Heater Setup menu you can set **the temperature** that the heater is expected to create in the sauna room.

While the **AUTO ON** icon is activated, the heater will switch on automatically when you press the **Sauna ON/OFF** icon. To switch on the heater with the AUTO ON icon deactivated, press the **Sauna ON** icon and then activate the **Heater ON/OFF** icon.

To keep your sauna in a good condition for longer, it is important that you have it dehumidified after bathing. With Fenix you can do this by leaving the heater on for a desired period at a temperature of 40 °C. Once the function is activated, it will stay on until the setting is changed by the user.

#### 2.4.2. Steamer Setup

The steamer is controlled through the Steamer Setup menu. One of the two modes must be selected:


**1) In the %RH Mode** (%RH = relative humidity expressed as a percentage) the humidity sensor measures the humidity in the sauna room and the wireless control unit controls the steamer so that the humidity level is maintained as close to the set value as possible during the bath.

Set the desired humidity %RH. The sum of the steamer %RH setpoint and the max. heater setup cannot exceed 140.


**2) The Interval Mode** means that the steamer is on and off periodically. Set the desired duration of the two periods: for example the ON period at 140 seconds and the subsequent OFF period at 85 s. Confirm the settings.

While the AUTO ON icon is activated, the steamer will switch on automatically when you press the **Sauna ON/OFF** icon.

From the Main Menu choose



From the Main Menu choose



## 2.5. Colour Light and Light Setup

The colour light settings are available only if your Fenix control unit is equipped with the colour light feature. The feature can also be retrofitted.

### 2.5.1. Colour Light Setup

To activate the colour light in your sauna room, press the **Colour Light** function icon. If you wish to change the colour light settings, choose **Colour Light Setup** from the Main Menu.

#### Colour Light Menu:

There are four colours to choose from: blue, red, green, and yellow. You can choose just one colour or cycle all the four colours.

1) To cycle the colours, set the cycle speed determining how long each colour is on at slow, medium, or fast.

2) To use just one colour, press **Change Colour** to choose the desired colour. The colour that is left displayed will stay on.


The **Set Brightness** icon is used to adjust the brightness of the colour light.

While the **AUTO ON** icon is activated, the colour light will switch on automatically when your sauna is ready for bathing.

While the **AUTO OFF** icon is activated, the colour light will switch off automatically after the desired delay period, which can be set at max. 90 minutes.

**Colour Light Unit Disabled** indicates whether the colour light is in use or not.


From the Main Menu choose



### 2.5.2. Light Setup

To activate the lighting of your sauna, press the **Light** icon in the **Start Menu**. If you wish to change the light settings, choose **Light Setup** from the **Main Menu**.

From the **Main Menu** choose



### Light Menu:

While the **AUTO ON** icon is activated, the lights will switch on automatically when your sauna is ready for bathing.

While the **AUTO OFF** icon is activated, the lights will switch off automatically after the desired delay period, which can be set at max. 90 minutes.





### 2.6. Fan Setup

To activate the fan of your sauna, press the **Fan** icon in the **Start Menu**. If you wish to change the fan settings, choose **Fan Setup** from the **Main Menu**.


#### Ventilation Menu:

The fan can be set to **switch on or off automatically**.

From the **Main Menu** choose



Delay, for example 25 min



While the **AUTO ON** icon is activated, the fan will switch on automatically when your sauna is ready for bathing.

While the **AUTO OFF** icon is activated, the fan will switch off automatically after the desired delay period, which can be set at max. 90 minutes.

If you activate the **Interval Mode**, the fan will be on and off periodically. Make the necessary ON and OFF settings: for example, set the fan to blow air into the sauna room for a period of 60 seconds (ON) and to switch OFF for the subsequent 60 s.

## 2.7. Week Timer

**Electrical safety regulations allow the week timer feature to be used only in community saunas!**

The week timer settings allow you to program a weekly schedule, which is especially handy if you use your sauna regularly every week. Set the desired bathing time for any chosen day – or even every day – of the week.

When the weekly schedule starts, the wireless control unit will be activated even if switched off.

A pause of at least 6 h is required between each two periods created for the Week Timer schedule.

### Week Timer Menu:

Choose **Enable Program** to activate all created programs to be run at set times.

**View Schedule** brings to the screen a recap of your weekly schedule if you have created one; if you do not have one, the display shows 'Week timer program is empty'. You can also change the schedule in this menu.

### Create New Program Timing

- Set the program start time, which is the time you wish to start bathing. Confirm or, if you wish to return to the previous screen, cancel.
- Set the program ending time and confirm or cancel.
- Set the day(s). You can set more than one day at the same time.
- Confirm the settings or press Cancel to return to the previous screen.
- Set the desired temperature for the programmed period.
- Set the desired humidity level for the programmed period. Make sure you have the Enable Steamer box ticked.

- Confirm the settings or press Cancel to return to the previous screen.

The display now shows a recap of the settings made. Confirm or press Cancel to return to the previous screen.



If you choose **View Schedule** again after programming, the displayed week timer schedule will contain the period you just programmed. Here you can change the schedule or, for example, remove a schedule without deleting it permanently, meaning that it will remain stored in the memory for later activation. You can also add/create new schedules. See the following pages for examples.

**Delete All Periods** deletes all the periods created for a week timer schedule. If you choose this option, the display will show a message asking you to confirm that you wish to delete all periods. Confirm or cancel as required.

**Check Validation** checks the status of the Week Timer schedule and displays any possible problems on the screen.

- Heating periods: checks the heating period length to make sure the max. operating time is not exceeded.
- Resting periods: checks that the pauses in the Week Timer schedule are at least 6 h.
- Periods enabled: displays the activated periods of the weekly schedule.
- Master enable: on / off.
- Check progress: indicates the stage of the check.

From the Main Menu choose







Press the **Page Change** icon to move to the next page.



**ATTENTION!** Required 6 h resting time between programs does not come true. Number indicates the amount of errors in the week program.


EN




Exit/Cancel



Change



Confirm/Next



Mon, Tue, Wed, Thu, Fri




Sat, Sun



Steamer enabled



To change or delete a created Week Timer period one at a time, choose **View Schedule**.



- Scroll through periods
- Recap of the period(s)
- Scroll through periods
- Activate period

- Return/Cancel
- New period
- Make changes
- Delete period

## 2.8. User Settings

Through the **User Settings** menu you can control settings related to the use of the wireless control unit.

### User Settings Menu:

#### Backlight Mode

Alternative modes:

- Backlight on while unit is on
- Backlight on during baths
- 2 min switch off delay
- 30 s switch off delay
- 10 s switch off delay
- Always off

### Display Contrast

Increase or decrease the contrast and brightness of the screen as necessary.

### Options

You can adapt the information on the display as follows:

- 1) You can replace the digital clock, displayed in the Start Menu by default, with an analogue clock.
- 2) You can choose the display to cycle any selected/activated data, such as energy consumption and/or heater output, during sauna baths. The informative screen contains, during sauna baths, a recap of the selected aspects, such as energy consumption and/or heater output.

**Panel Language**

Choose the language to be used by the wireless control unit.

**Key Beep Tone**

The tone range varies from silent to loud beep.

**Audible Notifications**

You can choose to hear a notification sound when your sauna is ready for bathing and/or when a week timer event becomes active.

**2.9. Miscellaneous**

**2.9.1. Statistics**

Pressing the **Statistics** icon brings to the screen a recap of the most recent sauna bath (total time and energy consumption). Before the first bath there is no data stored in the memory. Touch the screen to return to the previous screen.

**2.9.2. Curve Diagram**

The current readings of the temperature and humidity sensors or the readings taken during the most recent sauna bath are displayed as a graph.

**2.9.3. Adjust Current Time and Day**

Set the correct time and day. The clock must be adjusted for summer/winter time.

**2.9.4. Device Pair-Up**

This procedure is used to establish a connection between new devices/device pairs and to re-establish any lost connections. The icon in the upper left corner of the **Start Menu** indicates whether the connections are active or whether connections are missing.



Connection active



No connection

**Note!** The pair-up procedure is unnecessary if the wireless control unit is connected to the power unit with a cable. In this case the wireless control unit does not need batteries or charging, since the required operating voltage is supplied from the power unit through the cable.


**Device pair-up**

The following pair-up procedure is necessary to make the devices recognize each other and communicate:


1. Switch on the wireless control unit. The **Start Menu** is displayed.
2. Press the **Main Menu** icon. Use the page change to scroll through the Main Menu to **Miscellaneous** and select.
3. Use the page change to scroll to **Device Pair-Up** and select. This is the procedure to be used to establish a connection between devices/device pairs.
4. Under the selected menu item you will find the pair-up procedure menu. When you are establishing connections between device pairs for the first time, select **Help**. Read through the instructions and follow them.
5. Press the **Confirm** icon to switch back to the **Pair-Up Procedure** menu:



Pair-Up Procedure



Pair-Up Help, page 1



Pair-Up Help, page 2

**A) Click 'New code',** and the display will show 'Panel code changed. Renewing pairs is necessary.'

**C) Click 'Heater',** and the display will show 'Linking to Heater, switch power on now.'

**D) Turn power unit on within 10 seconds,** and the display will show 'Successful pair-up with heater.' If the pairing up was not successful, the display will show "Pair-up with heater FAILED". In this case, return to Step B and repeat the procedure according to the instructions.

6. To further add colour light, for example, press '**Colour light**'.

**NOTE!** If you press the 'New Code' icon again, all connections are lost and must be re-established!



Pair-Up icon for heater power unit



Pair-Up icon for colour light power unit

### 2.9.5. Panel Power Settings

Set the desired standby delay period after which the power to the wireless control unit is switched off.

### 2.9.6. Additional Options and Settings

Here you can activate a safety option which automatically switches off the power to the unit devices if the connections between them are lost. The factory setting of this feature is 'deactivated'.

### 2.9.7. Detailed Version Info

Here you can find information on the software, wireless control unit, power unit and, if installed, colour light unit included in the configuration. This information is needed when you update the software.

### 2.9.8. Sensor Reading Adjustment

Here you can change the readings of the temperature sensors (NTC thermistor) and the humidity sensor from the measured ones. The reading can be corrected by +/- 10 units. This adjustment is to ensure that the desired temperature is achieved in the sauna room. To find out the required correction, measure the temperature and, if necessary, humidity of the sauna room using external meters.

Temperature sensor A = the NTC thermistor is in the same box as the overheat protector.

Temperature sensor B = the NTC thermistor is in the same box as the humidity sensor.

Humidity sensor = the sensor measuring the humidity level in the sauna room.

**NOTE!** Correcting sensor readings do not affect the operation of the overheat protector. The overheat protector cuts off the power if the temperature around it exceeds 150 °C. See chapter 3.2.6. 'Resetting the Overheat Protector'.

### 2.9.9. Service Menu

To enter the Service Menu select **Miscellaneous** in the **Main Menu**. Use the arrow icon to scroll through to **Service Menu**. To access the **Service Menu**, you must enter **service code 6143**. The code is fixed and cannot be changed.

#### a) Auxiliary Relay Function

Power units SACF150 and SACF165S have a 230 V 1N~ auxiliary output which can be used for different functions.

#### Auxiliary Output Setup:


**Ventilation Fan:** Use the AUX output for controlling the fan (max. 100 W) of your sauna.

**Heating control:** Use the AUX output for controlling the electric heating of the building. The output gives 230 V 1N~ in Sauna ON mode.

**Indicator:** Use the AUX output for installing an indicator light (max. 100 W) that tells you when your sauna is ready for bathing.

#### b) Installed/Enabled Features

Here you can choose the devices acquired and enabled. When enabled, they will be displayed as



function icons on the touch screen of the wireless control unit. This way you can also adapt the amount of data displayed. The features available for selection are steamer, light, colour light and radio link.

For wireless communication you must have at least the radio link feature selected, since it enables the real-time communication between devices.

#### c) Heater Watts Setup

Here you can enter the **output of your heater** for the kWh meter. If you cannot find a suitable option from the list, enter the output in watts.

#### d) Steamer Watts Setup

Here you can enter the **output of your steamer** for the kWh meter. If you cannot find a suitable option from the list, enter the output in watts.

#### e) Max On Time Setup

- Family sauna 4 h, max. 6 h:  
Select the max. operating time for the heater. The week timer feature is not available in family saunas.
- Public sauna in an apartment building 4 h, 6 h, max. 12 h, pause time 6 h:  
Select the max. operating time for the heater, the week timer feature is in use. When creating a weekly schedule, bear in mind that the operating time must be followed by a 6-hour pause.
- *For longer operating times consult the importer/manufacturer.*

#### f) Load Factory Settings

You can restore the wireless control unit to its factory settings, which means that all the settings you have made are returned to the defaults.

During restore there must be connection to the power unit.

1. From the Main Menu select **Miscellaneous**.
2. Use the page change to scroll to **Service Menu** and select. Enter the **service code 6143** and confirm.
3. Use the page change to scroll through the menu to **Load Factory Settings** and select.
4. You are now asked to confirm that you wish to erase all the settings you have made, returning to the default settings chosen by the manufacturer. Confirm to restore the factory settings.

#### 2.10. Options

When you press the power switch lightly in the Sauna OFF mode, the **Options** menu appears on the screen. This menu is a short cut to the following functions:

**Standby mode**, for switching the screen to standby mode and switching off the power.

**Sauna on**, for switching on the sauna.

**Sauna on with delay**, for setting the pre-setting time after which the sauna starts heating up.

**Next**, takes you the next menu page.

**Calibration**, see chapter 2.10.1.



**Exit menu**, takes you back to the **Start Menu**.

##### 2.10.1. Calibrating the Touch Screen

Calibrate the screen if it stops responding or responds slowly. When you press the power switch in the Sauna OFF mode, the **Options** menu appears on the screen. To switch from one menu item to another, press the power switch repeatedly. To perform the calibration, first switch to **Next page**. Select a section by pressing the power switch for a longer time. Select **Recalibrate** and perform the calibration according to the displayed instructions on the screen.



→ Press the power switch in the **Sauna OFF** mode



### 3. INSTRUCTIONS FOR INSTALLATION

The electrical connections of the control unit may only be made by an authorised, professional electrician and in accordance with the current regulations. When the installation of the control unit is complete, the person in charge of the installation shall pass on to the user the instructions for installation and use that come with the unit and shall give the user the necessary training to use the heater and the control unit!

For an overall view of the Harvia Fenix control unit see Figure 1.

#### 3.1. Installing the Wireless Control Unit

The Fenix wireless control unit comes with a table recharge stand that can be attached to a table with a screw. The recharge stand can also be wall mounted using a separate wall-mounting plate. When installing the recharge stand, observe the distance to the nearest socket: the cord measures approximately 1,5 m in length. The wall-mounting plate is fixed to the wall with three screws, and the recharge stand is fastened to the plate with two screws. The recharge stand is installed outside the sauna room, in a dry place with an ambient temperature of  $>0\text{ }^{\circ}\text{C}$ . The wireless control unit can, if necessary, be attached to the charger with a screw. See Figure 2.

**Check the operating range of the radio link (up to 10 m from the power unit) when installing the recharge stand. The range varies according to the structural obstacles.**

The wireless control unit can, alternatively, be connected to the power unit with a cable. The required operating voltage is then supplied from the power unit through the cable and batteries can not be used. If connected to the power unit with a cable, the wireless control unit can be fixed to a wall using a special rear cover designed for wall mounting (see Figure 3). In this case you do not need a recharge stand.

When you first switch on the wireless control unit, it will automatically prompt you to calibrate the touch screen. The screen will guide you through the calibration process. After this you are asked to choose the desired panel language and set the day and time. Make the required settings and confirm. If the unit does not follow the above steps automatically, they can be carried out manually (see Quick Guide).

**Before the wireless control unit is taken into use, the installer shall enable the installed features through the Service Menu.**

To add or remove function icons on the screen:

1. Go to the **Main Menu**. 
2. Use the page change to scroll through to **Miscellaneous** and select.
3. Scroll to **Service Menu** and enter the service code 6143.  
Confirm by pressing  **Confirm/Next**.
4. Choose **Installed/Enabled** Features. Here you can activate the required features, which are then displayed as function icons on the touch screen of the wireless control unit.
5. Confirm the settings. 
6. Select the desired function for the auxiliary output and **Confirm**.






Figure 2. Wall mounting of the recharge stand.

**Figure 3. Wall mounting of the wireless control unit by means of a special wall-mounting cover.**



**Figure 4. Opening the power unit cover and mounting the unit to a wall.**






Figure 5. Wall mounting of the power unit.

### 3.2. Installing the Power Unit

The power unit of the Harvia Fenix control unit and the power unit for colour light, if installed, are placed outside the sauna room, in a dry place with an ambient temperature of  $>0\text{ }^{\circ}\text{C}$ . The power units can be fixed to a wall. See Figure 4 for instructions on how to open the power unit cover and how to fix the unit to the wall.

**Note! The power units must not be embedded into the wall, since this may cause excessive heating of the internal components of the unit and lead to damage. See Figure 5.**

#### 3.2.1. Electrical Connections of Power Unit SACF150 for Heater

Power unit SACF150 is designed for controlling electric heaters with an output of max. 15 kW.

This power unit can also be used for controlling the lighting (max. 100 W) in the sauna room and, through the auxiliary output (max. 100 W), the 'sauna ready' indicator light, ventilation fan or electric heating of the building. For instructions on

Table 1.

| Heater output kW | Fuse (A) | Supply cable | Connection cable 400V 3N~ |
|------------------|----------|--------------|---------------------------|
| 0-6 kW           | 3 x 10   | 5 x 1,5      | 5 x 1,5                   |
| <6-11 kW         | 3 x 16   | 5 x 2,5      | 5 x 1,5                   |
| <11-15 kW        | 3 x 25   | 5 x 6,0      | 5 x 2,5                   |

Table 2.

| Heater model | Output (kW) | Fuse (A) | Supply cable | Connection cable 400V 3N~ |
|--------------|-------------|----------|--------------|---------------------------|
| KV50SE       | 5,0         | 3 x 10   | 5 x 1,5      | 7 x 1,5                   |
| KV60SE       | 6,0         | 3 x 10   | 5 x 1,5      | 7 x 1,5                   |
| KV80SE       | 8,0         | 3 x 16   | 5 x 2,5      | 7 x 2,5                   |
| KV90SE       | 9,0         | 3 x 16   | 5 x 2,5      | 7 x 2,5                   |
| T7C          | 7,0         | 3 x 16   | 5 x 2,5      | 7 x 2,5                   |
| T9C          | 9,0         | 3 x 16   | 5 x 2,5      | 7 x 2,5                   |
| K11GS        | 10,3        | 3 x 16   | 5 x 2,5      | 5 x 1,5 + 4 x 1,5*        |
| K13,5GS      | 13,5        | 3 x 20   | 5 x 6,0      | 5 x 2,5 + 4 x 1,5*        |
| K15GS        | 15,5        | 3 x 25   | 5 x 6,0      | 5 x 2,5 + 4 x 1,5*        |

\*) For further instructions see the instructions for installation and use for Club Combi

how to select the desired AUX output function see chapter 2.9.9. a).

The temperature sensor in the sauna room must be connected to the SACF150 power unit. You can also install a humidity sensor, available as an accessory, for measuring the humidity level in the sauna. For instructions on how to install the sensors see chapter 3.2.5.

The electrical connections of the power unit are made according to Figure 6. For wireless communication, the power unit must be paired up with the wireless control unit after installation (see chapter 2.9.4).

Table 1 shows the cable thickness and fuse size, depending on the heater output, to be used with the Fenix SACF150 power unit. For more detailed installation instructions see the instructions for installation and use for the selected heater model.

#### 3.2.2. Electrical Connections of Power Unit SACF165S for Steamer/Heater

Power unit SACF165S is designed for controlling heaters of max. 15 kW, steamers of max. 5 kW, and Combi combined heaters/steamers of max. 16,5 kW.

This power unit can also be used for controlling the lighting (max. 100 W) in the sauna room and, through the AUX output (max. 100 W), the 'sauna ready' indicator light, ventilation fan or electric heating of the building. For instructions on how to select the desired AUX output function see chapter 2.9.9. a).

The temperature and humidity sensors in the sauna room must be connected to the SACF165S power unit. For instructions on how to install the sensors see chapter 3.2.5.

The electrical connections of the power unit are made according to Figure 7–9, depending on the heater model. For wireless communication, the power unit must be paired up with the wireless control unit after installation (see chapter 2.9.4).

Table 2 shows the cable thickness and fuse size, depending on the heater model, to be used with the Fenix SACF165S power unit. For more detailed installation instructions see the instructions for installation and use for the selected heater/steamer model.

#### 3.2.3. Electrical Installations of Power Unit SACF100 for Colour Light

Power unit SACF100 is designed to be used for controlling two Harvia Colour Lights with bulbs of max. 50 W / 12 V DC. The electrical connections are made according to Figure 10.

The colour light unit is connected to power unit SACF150 or SACF165S via the included cable measuring approximately 1,5 m in length. The Harvia Colour Light also comes with a cable (T 180  $^{\circ}\text{C}$ ) for connection to power unit SACF100.

The SACF100 unit is supplied with power (230 V 1N~) via an installation cable of 3 x 1,5 mm<sup>2</sup>.

To be able to use the power unit SACF100 for colour light, the colour light feature of the wireless control unit must be activated (see Chapter 2.5.1.), and for wireless communication, the colour light unit must be paired up with the wireless control unit (see Chapter 2.9.4).




Figure 6. Electrical connections of power unit SACF150 for heater




Figure 7. Electrical connections of power unit SACF165S for steamer/heater (Combi heaters)



# Power unit SACF165S

## Heater and steamer SS20/SS20A

Internal Cabling DO NOT TOUCH!




Figure 9. Electrical connections of power unit SACF165S (heater and SS20/SS20A steamer)




Figure 10. Electrical connections of power unit SACF100 for colour light

### 3.2.4. Installing the Radio Antenna

For wireless communication, the radio antenna must be connected to the SACF150 or SACF165S power unit. The antenna is attached near to the power unit (see Figure 11) using two-sided tape.

### 3.2.5. Installing the Temperature and Humidity Sensors

**Wall-mounted heaters and Combi heaters** (see Figure 12).

The temperature sensor is wall-mounted above the heater, along the vertical centre line running parallel to the sides of the heater, at a distance of 100 mm from the ceiling.

**Floor-mounted heaters and Combi heaters** (see Figure 13).

Alternative 1:

The temperature sensor is wall-mounted above the heater, along the vertical centre line running parallel to the sides of the heater, at a distance of 100 mm from the ceiling.

Alternative 2:

The temperature sensor is mounted to the ceiling above the heater, at a distance of 200 mm from the vertical centre line of the heater's side.

For installing the temperature sensor near vents see the instructions in Figure 14.

With a separate steamer (SS20/A), observe that the temperature sensor must not be installed in the area affected by steam (see Figure 13).

The humidity sensor is wall-mounted as far from the heater as possible and at a distance of 500–700 mm from the ceiling.




Figure 11. Installing the radio antenna of the Fenix control unit

### 3.2.6. Resetting the Overheat Protector

The components in the sensor box control the operation of the control unit. The sensor box contains a temperature sensor and an overheat protector. An

NTC thermistor senses the temperature, and the resettable overheat protector cuts off the heater power in the case of malfunction, after which the protector can be easily reset. The reset button of the overheat protector is shown in Figure 15.




Figure 12. Installing the temperature and humidity sensors of the Fenix control unit, wall-mounted heaters




Figure 13. Installing the temperature and humidity sensors of the Fenix control unit, floor-mounted heaters





Figure 14. Installing the temperature sensor near to a vent



Figure 15. Reset button of the overheating protector



Harvia Oy  
PL 12  
40951 Muurame  
FINLAND  
[www.harvia.fi](http://www.harvia.fi)